

220521_Final_Project_XRay_PreProcessing

May 21, 2022

1 Data Set Overview

1.1 PidRay

PIDray is a large-scale dataset which covers various cases in real-world scenarios for prohibited item detection, especially for deliberately hidden items. The dataset contains 12 categories of prohibited items in 47, 677 X-ray images with high-quality annotated segmentation masks and bounding boxes.

<https://github.com/bywang2018/security-dataset>

<https://paperswithcode.com/dataset/pidray>

1.2 SixRay

With unknown machine specification, this dataset is acquired from subway stations, SIXray dataset comprises 1,059,231 X-ray images, 8929 of which are manually annotated for 6 different classes: gun, knife, wrench, pliers, scissors, hammer, and background. The dataset consists of objects with a wide variety in scale, viewpoint and mostly overlapping, making it a suitable dataset for real-time classification, detection and segmentation applications.

https://github.com/MeioJane/SIXray/blob/master/data_list.txt

<https://github.com/MeioJane/SIXray/issues/9>

<https://github.com/jodumagpi/Xray-ObjSep-v1>

1.3 OpixRay Dataset

OPIXray dataset is an airport inspection dataset manually annotated by the security personnel. The dataset comprises 8885 X-ray images (7019 training, 1776 testing) from five sharp objects, including folding knife (1,993), straight knife (1,044), scissor (1,863), utility knife (1,978) and multi-tool knife (2,042).

https://drive.google.com/file/d/12moaa-ylpVu0KmUCZj_XXeA5TxZuCQ3o/view

Y. Wei, R. Tao, Z. Wu, Y. Ma, L. Zhang, X. Liu, Occluded Prohibited Items Detection: An X-ray Security Inspection Benchmark and De-occlusion Attention Module, in: Proceedings of the 28th ACM International Conference on Multimedia, ACM, New York, NY, USA, 2020, pp. 138–146.

1.4 GdxRay

Grima X-ray Dataset (GDXRAY) comprises 19, 407 X-ray samples from five various subsets including castings (2, 727), welds (88), baggage (8, 150), natural images (8, 290), and settings (152). The baggage subset is mainly used for security applications and comprises images from multiple-views. The limitation of this dataset is its non-complex content, which is non-ideal to train for real-time deployment.

<https://domingomery.ing.puc.cl/material/gdxray/>

After some initial data analysis, the Gdxray data set was not further used due to limitations like object classes. Additionally, the pictures were created synthetically and did not match with the original images from X-Ray scans.


2 Exploratory Data Analysis

```
[4]: # general
import pandas as pd
import numpy as np

# preprocessing
import xml.etree.ElementTree as ET
import io
import os
import matplotlib.pyplot as plt
from PIL import Image
```

```
[5]: # print a single image (gun on the left)
img = plt.imread('_data/data_ml_final_project/sixray/images/P00011.jpg')
plt.imshow(img)
```

```
[5]: <matplotlib.image.AxesImage at 0x1fbc48bd580>
```



```
[6]: def get_obj_num():
    obj_num = []
    for i in range(1,8828):
        img_id = 'P'+ '0'*(5-len(str(i)))+str(i)
        xml = ET.parse(f'_data/data_ml_final_project/sixray/annotation/{img_id}.
↪xml')
```

```

root = xml.getroot()
count_obj = 0
for obj in root.findall('object'):
    if type(obj.find('name')) is not type(None):
        count_obj += 1
obj_num.append(count_obj)
return obj_num

```

[7]: *# get number of pictures with a specific number (1-10) of objects*

```

nums = get_obj_num()
for i in range(11):
    print(i,": ",nums.count(i))

```

```

0 : 21
1 : 4152
2 : 2431
3 : 1174
4 : 501
5 : 416
6 : 93
7 : 17
8 : 5
9 : 16
10 : 1

```

[8]: *# create info of each picture and the count for how many objects are in the picture*

```

def create_info_df():
    #df = pd.
    DataFrame(columns=['Picture_Name', 'Num_Obj', 'Num_Gun', 'Num_Knife', 'Num_Scissors'])
    info = []
    for i in range(1,8828):
        img_id = 'P'+ '0'*(5-len(str(i)))+str(i)
        xml = ET.parse(f'_data/data_ml_final_project/sixray/annotation/{img_id}.
        xml')
        root = xml.getroot()
        c_gun, c_knife, c_scissors = 0,0,0
        for obj in root.findall('object'):
            if type(obj.find('name')) is not type(None):
                obj_name = obj.find('name').text
                if obj_name == "Gun":
                    c_gun += 1
                elif obj_name == "Knife":
                    c_knife += 1
                elif obj_name == "Scissors":
                    c_scissors += 1

```

```

        info.append([img_id+".jpg", c_gun+c_knife+c_scissors, c_gun, c_knife,
↪c_scissors])
    return info

```

```

[9]: df = pd.DataFrame(create_info_df(),
↪columns=['Picture_Name', 'Num_Obj', 'Num_Gun', 'Num_Knife', 'Num_Scissors'])

```

```

[10]: # get images with only one gun
df_gun_test = df.loc[(df['Num_Obj']==1) & (df['Num_Gun']==1)]

```

```

[11]: df_gun_test

```

```

[11]:
   Picture_Name  Num_Obj  Num_Gun  Num_Knife  Num_Scissors
795  P00796.jpg         1         1         0             0
967  P00968.jpg         1         1         0             0
972  P00973.jpg         1         1         0             0
973  P00974.jpg         1         1         0             0
979  P00980.jpg         1         1         0             0
...          ...      ...      ...      ...      ...
3743 P03744.jpg         1         1         0             0
3744 P03745.jpg         1         1         0             0
3745 P03746.jpg         1         1         0             0
3746 P03747.jpg         1         1         0             0
3747 P03748.jpg         1         1         0             0

```

[1195 rows x 5 columns]

```

[12]: # get images with only one knife
df_knife_test = df.loc[(df['Num_Obj']==1) & (df['Num_Knife']==1)]

```

```

[13]: df_knife_test

```

```

[13]:
   Picture_Name  Num_Obj  Num_Gun  Num_Knife  Num_Scissors
2    P00003.jpg         1         0         1             0
3    P00004.jpg         1         0         1             0
4    P00005.jpg         1         0         1             0
5    P00006.jpg         1         0         1             0
60   P00061.jpg         1         0         1             0
...          ...      ...      ...      ...      ...
8520 P08521.jpg         1         0         1             0
8752 P08753.jpg         1         0         1             0
8753 P08754.jpg         1         0         1             0
8754 P08755.jpg         1         0         1             0
8755 P08756.jpg         1         0         1             0

```

[588 rows x 5 columns]

Only pictures with one object are useful for training and best case for testing.

3 Pre-Processing

3.1 PidRay

```
[ ]: import json
import pandas as pd

f = open('_data/data_ml_final_project/pidray/train.json')
data = json.load(f)
df_json = pd.DataFrame.from_dict(data["annotations"], orient='columns')
#df_json = pd.DataFrame.from_dict(pd.json_normalize(data), orient='columns')
df_json
```

```
[8]: # print number of images within chosen classes
df_cat = df_json[df_json["category_id"].isin([2,5,6,7,11])]
df_cat["category_id"].value_counts()
```

```
[8]: 5      4352
6      4350
2      4236
11     3290
7      2178
Name: category_id, dtype: int64
```

```
[10]: # print number of images with one threat object in chosen classes
df_1 = df_cat.groupby('image_id').filter(lambda x: len(x) == 1)
df_1["category_id"].value_counts()
```

```
[10]: 6      2917
5      2763
2      2622
7      1960
11     1803
Name: category_id, dtype: int64
```

```
[ ]: print(df_json["categories"])
```

```
[185]: def pyray_json(init_path,output_path):
        f = open(f'{init_path}.json')
        data = json.load(f)
        df_json = pd.DataFrame.from_dict(data["annotations"], orient='columns')
        df_cat = df_json[df_json["category_id"].isin([2,5,6,7,11])]
        df_1 = df_cat.groupby('image_id').filter(lambda x: len(x) == 1)
        for i in df_1["image_id"]:
            index = '0'*(5-len(str(i)))+str(i)
            img_path = f'{init_path}/xray_easy{index}.png' # need to be change each
            ↪time with easy, hard, or hidden
            image= cv2.imread(img_path)
```

```
        cv2.imwrite(f'{output_path}/{df_1[df_1["image_id"]==i]["category_id"].  
→values[0]}/{i}.png',image)  
        return "done"
```

```
[182]: # DON'T RUN - images are already created  
# pyray_json("_data/data_ml_final_project/pidray/pidray/easy", "_data/  
→data_ml_final_project/pidray/pidray/new_easy")
```

3.2 SixRay

```
[14]: # crop one image based on the info in the xml file and save it to its specific
      ↪ folder
def crop_image(img,xml):
    root = xml.getroot()
    file_name = root.find('filename').text
    count = 1
    if file_name in set(df_gun_test['Picture_Name']):
        img_save = Image.fromarray(img, 'RGB')
        # greyscale every cropped image
        img_save_grey = img_save.convert('L')
        # save the image in the form of Knife_1_P00001.jpg
        img_save_grey.save(f"_data/data_ml_final_project/sixray/images_test/
        ↪Gun_{file_name}")
    elif file_name in set(df_knife_test['Picture_Name']):
        img_save = Image.fromarray(img, 'RGB')
        # greyscale every cropped image
        img_save_grey = img_save.convert('L')
        # save the image in the form of Knife_1_P00001.jpg
        img_save_grey.save(f"_data/data_ml_final_project/sixray/images_test/
        ↪Knife_{file_name}")
    else:
        for obj in root.findall('object'):
            if type(obj.find('name')) is not type(None):
                obj_name = obj.find('name').text
                xmin = int(float(obj.find('bndbox').find('xmin').text))-50
                if(xmin<0):
                    xmin+=50
                xmax = int(float(obj.find('bndbox').find('xmax').text))+50
                ymin = int(float(obj.find('bndbox').find('ymin').text))-50
                if(ymin<0):
                    ymin+=50
                ymax = int(float(obj.find('bndbox').find('ymax').text))+50
                # crop the annotated part out of the image
                img_crop = img[ymin:ymax, xmin:xmax]
                img_save = Image.fromarray(img_crop, 'RGB')
                # greyscale every cropped image
                img_save_grey = img_save.convert('L')
                # save the image in the form of Knife_1_P00001.jpg
                img_save_grey.save(f"_data/data_ml_final_project/sixray/
                ↪images_crop/{obj_name}/{obj_name}_{count}_{file_name}")
                count += 1

# crop all positive images
def crop_all_images():
    for i in range(1,8828): #8828
```



```

img_id = 'P'+ '0'*(5-len(str(i)))+str(i)
xml = ET.parse(f'_data/data_ml_final_project/sixray/annotation/{img_id}.
→xml')
img = plt.imread(f'_data/data_ml_final_project/sixray/images/{img_id}.
→jpg')
crop_image(img,xml)

# get the name of all classes in the SIXRAY dataset
def get_obj_names():
    obj_all = []
    for i in range(1,8828):
        img_id = 'P'+ '0'*(5-len(str(i)))+str(i)
        xml = ET.parse(f'_data/data_ml_final_project/sixray/annotation/{img_id}.
→xml')
        root = xml.getroot()
        for obj in root.findall('object'):
            if type(obj.find('name')) is not type(None):
                obj_name = obj.find('name').text
                if obj_name not in obj_all:
                    # append unique categories
                    obj_all.append(obj_name)
                    # comment out the creation of folders since it was already
→done
                    #os.mkdir(f'_data/data_ml_final_project/sixray/images_crop/
→{obj_name}')
                return obj_all

def get_obj_size():
    obj_all = []
    for i in range(1,8828):
        img_id = 'P'+ '0'*(5-len(str(i)))+str(i)
        xml = ET.parse(f'_data/data_ml_final_project/sixray/annotation/{img_id}.
→xml')
        root = xml.getroot()
        for obj in root.findall('object'):
            if type(obj.find('name')) is not type(None):
                xmin = int(float(obj.find('bndbox').find('xmin').text))
                xmax = int(float(obj.find('bndbox').find('xmax').text))
                ymin = int(float(obj.find('bndbox').find('ymin').text))
                ymax = int(float(obj.find('bndbox').find('ymax').text))
                # create list element for width, height, size and category of
→each image
                obj_all.append([xmax-xmin, ymax-ymin,
→(xmax-xmin)*(ymax-ymin),obj.find('name').text])
            return obj_all

```

```
[15]: # DON'T RUN - cropped images are already created
# crop_all_images()
```


```
[16]: # get the different categories
get_obj_names()
```

```
[16]: ['Knife', 'Gun', 'Wrench', 'Pliers', 'Scissors']
```


```
[17]: # create a data frame for the sizes of the images and their categories
data_sizes = pd.DataFrame(get_obj_size())
data_sizes_cust = data_sizes

# possibility to filter
data_sizes_cust = data_sizes[data_sizes[3] == "Gun"]
```

```
[18]: # plot distribution of width and height of the cropped images
plt.figure()
plt.plot(data_sizes_cust[0], data_sizes_cust[1], 'bo', markersize=1)
plt.show()
```




```
[19]: # plt distribution of size of the cropped images
plt.hist(data_sizes_cust[2], density=True, bins=100, color='blue')
plt.show()
```




```
[20]: # create a data frame for the sizes of the images and their categories
data_sizes = pd.DataFrame(get_obj_size())
data_sizes_cust = data_sizes

# possibility to filter
data_sizes_cust = data_sizes[data_sizes[3] == "Knife"]
```

```
[21]: # plot distribution of width and height of the cropped images
plt.figure()
plt.plot(data_sizes_cust[0], data_sizes_cust[1], 'bo', markersize=1)
plt.show()
```



```
[22]: # plt distribution of size of the cropped images
plt.hist(data_sizes_cust[2], density=True, bins=100, color='blue')
plt.show()
```



3.3 OpixRay

```
[16]: # crop one image and save it to its specific folder
def crop_image_opixray(img,txt):
    info = open(txt,'r')
    info_read = info.read()
    info_list = info_read.replace('\n',' ').split(' ')
    for i in range(0,int((len(info_list)-1)),6):
        file_name = info_list[i+0]
        obj_name = info_list[i+1]
        xmin = max(int(info_list[i+2]),0)
        xmax = max(int(info_list[i+4]),0)
        ymin = max(int(info_list[i+3]),0)
        ymax = max(int(info_list[i+5]),0)
        # crop the annotated part out of the image
        img_crop = img[ymin:ymax, xmin:xmax]
        img_save = Image.fromarray(img_crop, 'RGB')
        # greyscale every cropped image
        img_save_grey = img_save.convert('L')
        # save the image in the form of Knife_1_0090000.jpg
        #plt.imshow(img_crop)
        #print(obj_name)
        img_save_grey.save(f"_data/data_ml_final_project/opixray/images_crop/
→{obj_name}/{obj_name}_{i}_{file_name}")

# get the name of the images
def get_img_names_opixray():
    img = open('_data/data_ml_final_project/opixray/_images_train.txt','r')
    img_read = img.read()
    img_names = img_read.replace('\n',' ').split(' ')
    return img_names[:-1]

# crop all images
def crop_all_images_opixray():
    for i in get_img_names_opixray():
        txt = f'_data/data_ml_final_project/opixray/annotation/{i}.txt'
        img = plt.imread(f'_data/data_ml_final_project/opixray/images/{i}.jpg')
        crop_image_opixray(img,txt)

# get a list of distinct images categories
def get_obj_names_opixray():
    obj_names = []
    for i in get_img_names_opixray():
        info = open(f'_data/data_ml_final_project/opixray/annotation/{i}.
→txt','r')
        info_read = info.read()
        info_list = info_read.replace('\n',' ').split(' ')
```

```
    obj_name = info_list[1]
    if obj_name not in obj_names:
        obj_names.append(obj_name)
        #os.mkdir(f'_data/data_ml_final_project/opixray/images_crop/
↪{obj_name}')
    return obj_names
```

```
[17]: get_obj_names_opixray()
```

```
[17]: ['Straight_Knife',
       'Folding_Knife',
       'Scissor',
       'Utility_Knife',
       'Multi-tool_Knife']
```

```
[18]: # DON'T RUN - cropped images are already created
      #crop_all_images_opixray()
```